

BETA

1.6,2.0 Saloon, HPE
& Saloon ES
1980-85

TREVI

1.6,2.0 Saloon
1981-85

Notes


From Chassis no. 22325.

System Ref.
51007

Kit Ref.
-

LA35C

82371470



LA34D

82376917



LA24T

82384217



BETA


1.6 Coupe & Spyder
1974-79

System Ref.
51011

Kit Ref.
-

LA16E

82327703



LA6J

82322193



LA10M

823828841



BETA


2.0 Coupe & Spyder
1976-79

System Ref.
51012

Kit Ref.
-


LA35C

82320954



LA6J

82322193



LA10M

823828841



BETA

1.6,2.0 Coupe & Spyder
1979-80

System Ref.
51013

Kit Ref.
-


LA35C

82371470



LA6J

82322193



LA10M

823828841



BETA

1.6 Coupe
2.0 Coupe & Spyder
1980-85

System Ref.
51015

Kit Ref.
-

LA35C

82371470



LA22W

82376919



LA23V

82369842

