

SPORT WIRING DIAGRAM

(on cars intended for countries where the fitting of emergency signalling is required)

1. Low beam
2. Main beam
3. Coolant radiator fan motor
4. Plug-in junction
5. Horns
6. Coolant radiator fan motor fuse
7. Coolant radiator fan motor thermostat switch
8. Front side light
9. Front direction indicator
10. Front direction indicator
11. Junction block (2 outlets)
12. Carburettor choke warning light switch
13. Voltage regulator
14. Alternator
15. Starter motor
16. Battery
17. Carburettor fast idling control solenoid
18. Direction indicator repeater
19. Oil pressure gauge transmitter
20. Coolant temperature gauge transmitter
21. Brake fluid low level warning light switch
22. Ignition distributor
23. Ignition coil
24. Fast idling control press-switch on gearbox
25. Fast idling control press-switch on clutch
26. Two-speed windshield wiper motor
27. Engine compartment light press-switch
28. Air ventilation fan two-speed motor
29. Junction block (6 outlets - white)
30. Fuse box
31. Low beam solenoid switch
32. Main beam solenoid switch
33. Emergency light switch with reserve warning light
34. Fuel gauge with reserve warning light
35. Coolant temperature gauge
36. Oil pressure gauge
37. Instruments junction block (8 outlets - white)
38. Rear window opening motor fuse (15 A)
39. Instruments lights
40. Instruments panel inner light
41. Emergency signalling light flasher
42. Emergency light switch with reserve warning light
43. Heated rear window glass
44. Fuel gauge transmitter
45. Rear window opening motor
46. Rear window motor stroke limiting switch
47. Rear direction indicator
48. Rear side light
49. Stop light
50. Number plate lamp
51. Reversing lamp
52. Electronic revolution counter
53. Carburettor choke warning light
54. Instruments junction block (8 outlets - red)
55. Emergency light change-over switch with warning light
56. Electric clock with light
57. Left direction indicator warning light
58. Main beam warning light
59. Handbrake and brake fluid low level warning light (flashing)
60. Alternator warning light
61. Side light warning light
62. Right direction indicator warning light
63. Windscreen washer motor
64. Junction block (4 outlets - white)
65. Cigarette lighter with light
66. Handbrake and brake fluid low level warning light flasher
67. Engine ignition and accessories key switch with anti-theft device
68. Cigarette lighter fuse
69. Air ventilation and heating fan motor switch
70. Direction indicators flasher
71. Jack
72. Junction block (4 outlets - red)
73. Side light, low beam and main beam switch
74. Direction indicator and headlamp flashing control
75. Horns control
76. Windscreen wiper 2-speed and washer motor control
77. Rear window opening motor solenoid switch
78. Rear window opening motor switch
79. Handbrake warning light switch
80. Stop light switch
81. Reversing light press-button switch
82. Heated rear window glass
83. Open door marker lamp
84. Courtesy light door-operated press-button switch
85. Emergency light switch with reserve warning light
86. Instruments panel inner light
87. Emergency signalling light flasher
88. Heated rear window glass
89. Fuel gauge transmitter
90. Rear window opening motor
91. Rear window motor stroke limiting switch
92. Rear direction indicator
93. Rear side light
94. Stop light
95. Number plate lamp
96. Reversing lamp

Bianco = White
 Blu = Blue
 Giallo = Yellow
 Grigio = Grey
 Marrone = Brown
 Nocciole = Hazel
 Nero = Black
 Rosso = Red
 Verde = Green

